

WARRANTY

All Smart Firearms Training Devices come with a standard 90 day warranty, which can be extended for up to two years from purchase. If you require warranty service, or have any questions, please contact us. You can also check our websites FAQ page for common questions. www.smartfirearms.us



Questions, concerns, or suggestions? Please call us.

602-300-4645

Firearms Accidents? Not on OUR Watch! Thank you for your service!



Smart Firearms Training Devices

315 W. Elliott Rd, Suite 107-204
Tempe, Arizona 85284

info@smartfirearms.us
www.smartfirearms.us



MANUAL SF-25 & SF-30 PRO

Operating and
Programming
Instructions

Smart Firearms Training Devices

S

602-300-4645
www.smartfirearms.us

NOT ON OUR WATCH!

Proper training is crucial. Smart Firearms Training Devices has created a revolutionary training gun designed for instructors that desire immediate feedback on proper use of force, trigger manipulation, and proper finger indexing. Smart Firearms are designed to stop accidental and negligent discharges and to provide the perfect training gun for your reality-based training program, defensive tactics, and firearms instruction.

NO MORE "BANG, BANG"

Our SF-25 and SF-30 Pro Models come with a functioning / resetting trigger, removable magazine, adjustable night sights, realistic weight and feel, electronically-generated gunshot noises, and a patented Accidental Discharge Sensor which alerts the instructor and student when the finger is in the trigger well but no shots are being fired. There are also optional red or infrared lasers available for these models that can be used by themselves, and with most laser simulators and other laser training products on the market.

AVAILABLE MODELS

-SF-25 models are designed to fit most Smith and Wesson M&P and Sig Sauer P320 style holsters.

-SF-30 models are designed to fit most full-size Glock-style holsters.



GETTING STARTED

Our Devices come with batteries installed. To remove/replace batteries, take out the top screw and remove the cover. Inside you will see the batteries. Replace as needed. The Accidental Discharge Sensor is not activated for shipping purposes. To turn it on pull back the trigger all the way and hold it for approximately 9 seconds. After that time you will hear the gun emit a single tone. Take your finger off the trigger and keep everything away from the trigger area. The Accidental Discharge Sensor will calibrate itself for about 25-30 seconds. You will hear the gun emit tones as it is doing this to tell you it's still calibrating. The tones will get quicker near the end of calibration and end with a double tone. Once the gun does not emit anymore tones the calibration is done. To turn off the sensor, pull back and hold the trigger for 9 seconds until you hear a double tone emit. The Accidental Discharge Sensor Alarm is now off.

FUNCTIONS

The gun has a realistic, resetting trigger. When the trigger is pulled a gunshot noise will emit from the rear speaker and a green LED light will flash on each side of the gun slide for 9 seconds, showing the instructor a student has fired. Once the Accidental Discharge Sensor is active if a finger is placed in the Accidental Discharge Zone (inside the trigger well) but no shot is fired, then an alarm will sound and an orange LED light will flash on each side of the slide for 9 seconds alerting the instructor to which student was responsible for the alarm as well as reinforcing to the student the need to index their finger when not firing.

Smart Firearms Training Devices



For any product issues, please email info@smartfirearms.us
or call us at 602-300-4645